

MBRP

MBRP Muffler Installation Instructions

1080209-1085207

1097208-1097526

1095306

2000-2001

2000-2001

1999-2001

800 MXZ /SUMMIT

700 MXZ / SUMMIT

500-600 MXZ / SUMMIT

Note: Local regulations may limit or prohibit modification to your snowmobile's emissions system and/or the sound levels that it generates. It is your responsibility to be aware of restrictions that may apply to your intended use of this product.

1. Remove the springs fastening the stock muffler to the frame and the exhaust pipe and lower the bracket nut. (Set springs and nut safely aside so they can be reused)
2. Remove stock muffler.
3. Install MBRP muffler, inserting the end of the mounting bracket into the stock rubber, and placing its outlet through the stock exit in the belly pan.
4. Using the stock springs, fasten the MBRP muffler using the tabs on inlet pipe.
5. Tighten the lower bracket nut onto MBRP muffler tab.

NOTE: To avoid exhaust leaks use high heat silicone to seal all connections between expansion chambers and muffler. Monitor for leaks during the first 200 miles after your installation and re-apply silicone where necessary. We suggest having your local snowmobile mechanic or performance shop install this product.

CAUTION: **DO NOT** touch muffler while snowmobile is running or shortly after it has run, as it may result in personal injury.

MBRP Ltd warranty applies for a two (2) year period from the date of purchase to defects in product material and workmanship and is to the original purchaser on record and for the original vehicle for which it was designed and installed. This warranty is limited, at MBRP Ltd. sole determination, to the repair or replacement of defective product only and does not include the cost of removal or re-installation, damage by accident, abuse, misuse or misapplication or any consequential damages however they may arise. Determination of warranty coverage shall be at the discretion of an authorized MBRP Ltd quality engineer.