



2004.5-2021 5.9L and 6.7L Cummins Brake Master

Cylinder Reservoir Cover

Covers installation of PN: WCF100209



1. Loosen the upper left bolt holding the master cylinder to the hydrobooster.



2. Slide the mounting bracket in onto the bolt and tighten. Make sure the mounting point for the reservoir cover is vertically level.



3. Remove the brake reservoir cap. Remove the rubber gasket from the factory cap and transfer it to new billet cap if using (sold separately).



4. Install powder coated cover by slipping in at an angle. Be sure to not break the level sensor (circled in photo). Make sure the cover is on the outside of the mounting bracket that was previously installed in step 2.



5. Install both Allen head bolts to mount the cover to the mounting bracket.



6. Install billet reservoir cover cap or your OEM plastic brake reservoir cap if you have not also purchased our billet cap separately.



Any Questions, Comments, or Feedback?

Reach us by Email- Sales@wcfab.com

Or the shop phone- 630-277-8239

Thank you for purchasing from Wehrli Custom Fabrication!