



## L5P Fender Marker Light Delete

Covers installation of PN: WCF100390, WCF100391, WCF100392, WCF100393

### Front Marker Delete

1. Remove wheels and tires.



2. Remove inner fenders using T-15 screwdriver.





3. Remove connector for marker lamp.



4. Install isolating plug to vehicle side wire harness. You should hear a click when installed.
5. Zip the connector out of the way as seen in photo.



6. From the back side of the lamp assembly, remove these two T-20 screws and pull the lamp out.



7. Install the WC Fab delete into the truck and use supplied hardware (**not** the factory T-20).



8. Reinstall the inner fender. Install the wheels and tires and torque to factory specs.





### Rear Marker Delete

1. Lift rear and support truck.



2. Remove the wheels and tires.



3. Remove the mud flaps.



4. Remove the fender liner, which consists of two 10 mm plastic nuts, one screw nut on top and all T-15 screws.



5. Disengage most of the fender clips exposing the light.



6. Disconnect the light connector.



7. Install the connector plug/cap.



8. Zip tie the wire harness out of the way.





9. Remove the light (two T-20 screws).



10. Install new delete with two Phillips screws.



11. Reinstall the clips to the fender.



12. Clip the fender back in place.



13. Install fender lines.



14. Install the mud flaps.



15. Install the wheels and tires and torque to factory specs.

Any Questions, Comments, or Feedback?

Reach us by Email- [Sales@wcfab.com](mailto:Sales@wcfab.com)

Or the shop phone- 630-277-8239

Thank you for purchasing from Wehrli Custom Fabrication!