



2010-2018 Dodge Upper Coolant Pipe

Covers installation of PN: WCF100517

1. Drain the coolant.
2. Remove the factory coolant hose.
3. Coat the insides of the boots with Assemblee Goo or equivalent grease.
4. Install the boot and clamps on thermostat housing.



5. Install the boot on radiator.
6. Install the coolant pipe into the thermostat boot all the way.



7. Using screwdriver or pick, run boot around the end of the pipe while pushing into the boot.



8. Install clamps.



9. Fill coolant.

Any Questions, Comments, or Feedback?

Reach us by Email- Sales@wcfab.com

Or the shop phone- 630-277-8239

Thank you for purchasing from Wehrli Custom Fabrication!